

Sensors alert all the time. What can I do about it?

- An alert is triggered if a temperature is low or high for too long. Look at the last 2-week chart and determine the reason.
- If the temperature is always out of range, then adjust the equipment settings or request maintenance.
- If the alert is due to the temperature being too high for a reason, such as regular product loading or constant use, then increase the alert time threshold in the program. For example, if you see that the temperature regularly stays for 1 hour every morning, then set the alert threshold to 1 hr 30 min.