

## To Reset the Calibrations to Factory Defaults

**CAUTION:** Operators must verify accurate function of your pPhoenix XL Meter before taking measurements

Step	Starting Screen	Action	Screen Displayed
1D	Measure 14.0 mS 22.9 °C 4.0 pH Menu ↓ Hold	From the 'Home' screen, press  .	Select Menu Calibrate Units → Other Meas. ↑ Select
2D	Select Menu Calibrate Units → Other Meas. ↑ Select	Move cursor to the 'Other' selection and press  .	Select Menu Auto-Off New Battery → Factory Set Meas. ↑ Select
3D	Select Menu Auto-Off New Battery → Factory Set Meas. ↑ Select	Move cursor to the 'Factory Set' selection and press  .	Confirm Reset to Factory Defaults ? No [ ] Yes
4D	Confirm Reset to Factory Defaults ? No [ ] Yes	Press  for 'Yes', or  for 'No' if you want to keep the last user calibration.	Saving...

- This function restores the meter to the last factory calibration operating point
- Reset should only be used to recover a meter which is not calibrating properly.
- Always perform a user calibration and verify accuracy after restoring factory defaults.